

[Dec-2016-NewGet Braindump2go Cisco 010-151 PDF Dumps for 100% Passing the 010-151 Exam[NQ31-NQ40]

2016/12 New Cisco 010-151: Supporting Cisco Data Center System Devices Exam Questions Updated Today! Free Instant Download 010-151 Exam Dumps (PDF & VCE) 85q from Braindump2go.com Today! 100% Real Exam Questions! 100% Exam Pass Guaranteed! 1. | 2016/12 New 010-151 Exam Dumps (PDF & VCE) 85q Download: <http://www.braindump2go.com/010-151.html> 2. | 2016/12 New 010-151 Exam Questions & Answers: <https://1drv.ms/f/s!AvI7wzKf6QBjgUA0ldnAmKoPR142> QUESTION 31 Which three options are the minimum browser requirements to log into the Cisco CIMC GUI? (Choose three.) A. Java 1.6 or higher B. HTTP and HTTPS enabled C. Adobe Flash Player 10 or higher D. Internet Explorer version 10 E. Firefox 26.0 F. Adobe Shockwave Player 11 or higher Answer: ABC QUESTION 32 Which tool does a network administrator not need when installing hardware? A. cable tester B. wrench set C. cable wraps D. needle-nose pliers E. PCMCIA memory F. soldering iron with grounded tip Answer: F QUESTION 33 When the Cisco UCS Manager is used to verify the B- or C-Series device, which two types of Overall Status are acceptable and do not indicate a failure? (Choose two.) A. Online B. OK C. Unassociated D. Active Answer: BC QUESTION 34 What is the correct path to verify the Overall Status of Chassis 1 | Server 3? A. Equipment Tab > Chassis > Chassis 1 > Servers > Server 3 Status tab B. Equipment Tab > Chassis > Chassis 1 > Servers > Server 3 General tab C. Equipment Tab > Chassis > Chassis 1 > Servers > Server 3 FSM tab D. Servers Tab > Chassis > Server 3 General tab E. Status Tab > Chassis > Chassis 1 > Servers > Server 3 F. Admin Tab > Chassis > Chassis 1 > Servers > Server 3 General tab Answer: B QUESTION 35 If the Overall Status for a Cisco UCS B-Series Blade Server indicates a failure in the Cisco UCS Manager, such as discovery-failed, which statement is true? A. The server shuts down. B. The server automatically reboots in 3 minutes. C. The endpoints on that server cannot be upgraded. D. The server is online, but the administrator cannot assign a service profile to that blade. Answer: C QUESTION 36 Which action should the administrator take before physically removing a blade server for maintenance or replacement? A. Force the server to shut down. B. Disassociate the service profile. C. Decommission the server. D. Perform a graceful shutdown of the server. Answer: C QUESTION 37 Which three statements about powering down a Cisco UCS C-Series Rack-Mount Server to perform maintenance or replacement are true? (Choose three.) A. Standby power mode: Power is supplied only to the service processor and the cooling fans, and it is safe to power off the server from this mode. B. Power status LED. Green indicates that the server is in main power mode and can be safely powered off. C. Graceful shutdown: Press and release the power button. The operating system performs a graceful shutdown, and the server goes to standby mode, which is indicated by an amber power status LED. D. Disconnect the power cords from the power supplies in your server to completely power off the server. E. Only an emergency shutdown can be performed using the power button on the server front panel. F. The Cisco UCS C-Series Rack-Mount Server has only one power mode. Answer: ACD QUESTION 38 Which three components are hot swappable in a Cisco UCS Blade Server and Chassis? (Choose three.) A. Fabric Extender B. Power supply C. Heat sink D. SAS Hard Drive E. 2x8GB Kit DIMMs F. Mezzanine card Answer: ABD QUESTION 39 Which five things should the administrator verify after performing maintenance or replacing a blade server? (Choose five.) A. blade server status B. hard drive status C. host OS boot status D. CPU status E. mezzanine card status F. memory DIMM status G. fan and power status Answer: A,B,D,E,F QUESTION 40 Which two statements about DIMM replacement in Cisco UCS Servers are true? (Choose two.) A. In blade servers, DIMMs can be installed in either 1, 2, 4, or 8 DIMMs per channel. B. Rack-mount and blade servers have memory fault LEDs that indicate which DIMM requires attention. C. In servers that require pairs of DIMMs, the pairs must be identical (manufacturer, size, part #, and so on). D. If the memory in a server is not fully populated, you can install DIMMs in any open slot. Answer: AC !!!RECOMMEND!!!
1. Braindump2go | 2016/12 New 010-151 Exam Dumps (PDF & VCE) 85q Download: <http://www.braindump2go.com/010-151.html>
2. Braindump2go | 2016/12 New 010-151 Exam Questions & Answers: YouTube Video: [YouTube.com/watch?v=Q9lmi-oPiI](https://www.youtube.com/watch?v=Q9lmi-oPiI)